


Keep in contact

Check your contact list

Easily communicate with people that matter to you. The Contacts app lists all contacts you've stored on your phone and from online accounts you're logged in to.

- 1 Open the **Contacts** app.
- 2 On your contacts list, you can:

- View and edit your profile.
- Create, edit, find, or send contacts.
- See new message notifications, social network updates, and more.




Add a new contact

- 1 On the Contacts tab, tap **+**.
- 2 Tap the **Name** field, and then enter the contact name.
- 3 Select the Contact type, which indicates the account the contact will sync with.
- 4 Enter the contact information in the fields provided.
- 5 Tap **Save**.

Capture entire moments

Take great photos and videos with the camera, and make them more memorable by applying a variety of effects and scenes.



With HTC Zoe™, experience a whole new way of capturing, viewing, and sharing memories.

Take HTC Zoe Photos

Capture entire moments with pictures and sound, and watch them come alive again.

- 1 Open the **Camera** app.
- 2 Tap **10i**.
- 3 When you're ready to capture, tap **10i**.
- 4 To complete the recording, hold the phone steady until you see the shutter release icon turn red.

Share memorable moments

Create a collage of your best photos and share them with friends and family.


- 1 Open the **Gallery** app.
- 2 Tap **▼** > Events, and then tap a tile to see the photos taken at a certain event.
- 3 Tap **HTC Share**.
- 4 Tap **Upload**.
- 5 Under Share to, select how you want to share your collage.

Sync music and more

Whether you're at your computer or on the move, HTC Sync Manager lets you enjoy the same rich media. It also stores your same contacts, documents, and other data on both your phone and your computer (compatible with Windows® and Mac OS®).

Install HTC Sync Manager

- 1 Download the HTC Sync Manager installer from the HTC support site (www.htc.com/support).
- 2 Launch the installer and follow the onscreen instructions.
- 3 Connect your phone to your computer using the supplied USB cable. HTC Sync Manager opens.



Back up your stuff

Use HTC Backup to regularly back up to your Dropbox storage so that next time you can easily restore content such as:

- Home screen layout, feeds, and widgets.
- Email and social network accounts and passwords. (except Google® and Facebook).
- Apps and settings, including web bookmarks, Wi-Fi networks, apps you've installed, and more.

Backup your phone

- 1 Slide the Notifications panel open, and then tap **Settings**.
- 2 Tap **Backup & reset**.
- 3 Tap the **Backup On/Off** switch.
- 4 Choose **HTC Account** as your backup account, and sign in to your account.
- 5 Sign in to Dropbox, if you haven't done so.

Note: Dropbox services provided by a third-party. Use of Dropbox subject to terms and conditions, which may include a subscription fee after your two year free trial ends.

Keep it kid-friendly

Worried that your kids might wander off to inappropriate web sites or mess with your important work files while using your phone? With Kid Mode®, your children have their own space to enjoy:

- Parent-approved games and apps
- Recorded storybook readings
- Age-appropriate features such as an art board, video messaging, and more

Open the Kid Mode app and follow the instructions to set up your account. To learn more about Kid Mode, visit www.zoodles.com.

Download more apps

Find new apps in Google Play™ Store for your phone. Choose from a wide variety of free and paid apps ranging from productivity apps, entertainment, to games.

- 1 Open the **Play Store** app.
- 2 Browse or search for an app.
- 3 When you find the app that you like, tap it and read its description and user reviews.
- 4 To download or purchase the app, tap **Install** (for free apps) or the price button (for paid apps).
- 5 Tap **Accept & download** or **Accept & buy**.

ADDITIONAL INFORMATION

Use of some features, content or services may incur separate, additional charges and/or require a qualifying rate plan, or access to a Wi-Fi connection.

Messaging/Data: You will be charged for all messages and data sent by or to you through the network, regardless of whether or not data is received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications. Your data session, plan, or service may be **slowed, suspended, terminated, or restricted** if you use your service in a way that interferes with or impacts our network or ability to provide quality service to other users, if you roam for a significant portion of your usage, or if you use a disproportionate amount of bandwidth during a billing cycle. You may not use your plan or device for prohibited uses.

Downloads/Applications: T-Mobile is not responsible for any third party content or Web site you may be able to access using your phone. Additional charges may apply; not all downloads available on all phones. You obtain no rights in downloads; duration of use may be limited and downloads may be stored solely for use with your phone. T-Mobile is not responsible for any download lost due to your error. T-Mobile is not responsible for Apps, including download, installation, use, transmission failure, interruption or delay, third party advertisements you may encounter while using an App, alterations any App may make to the functionality of your device, **including any changes that may affect your T-Mobile plan, service, or billing, or any content or website you may be able to access through an App.**

Mobile Security: Capable phone required; technical limitations may prevent certain features (e.g., LOCK) from working on certain phones. Enabling the location history features of Mobile Security can cause your phone's battery life to diminish more quickly. Device must be powered on, have text messaging capability, and be within the T-Mobile coverage area for Mobile Security features to function. Data usage applies for download and use of Mobile Security. As with other software, Mobile Security may be disabled or uninstalled by other applications, software, devices or hacking. In this event the protective features of Mobile Security may not function properly. In addition, even though installed, Mobile Security may not function properly due to other prior installed software on your device.

Coverage: Not available everywhere.

Devices and screen images are simulated. See brochures and **Terms and Conditions (including arbitration provision)** at T-Mobile.com, for rate plan information, charges for features and services, coverage maps, and restrictions and details.

T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. © 2013 T-Mobile USA, Inc. HTC, the HTC logo, HTC One, and HTC Zoe are trademarks of HTC Corporation. Google and Google Play are trademarks of Google Inc. Kid Mode is a trademark of Inquisitive Minds, Inc. Mac OS is a trademark of Apple Inc. Windows is a trademark of Microsoft Corporation.

CEC Appliance Efficiency Compliance



The BC logo (shown at the left) indicates that this product complies with the California Energy Commission (CEC) energy efficiency standards for battery charger systems set forth at California Code of Regulations Title 20, Sections 1601 through 1608.



welcome

user guide



htc one



Before you do anything else, please read this

Charge the battery

Your phone hasn't been charged yet. Please use the supplied power adapter to do a full charge before using it. Also, please don't try to take your phone apart. (If you do, it may invalidate your warranty.)

Know about privacy laws

Some countries have strict laws about how and when you can record phone conversations. It's a good idea to find out what the laws are where you live before you use your phone's recording feature.

Safety tips

Consider device compatibility

If you have a pacemaker or hearing aid, check with your doctor to make sure it is safe for you to use a cell phone. In some cases, cellular radio frequencies can disrupt the performance of other electronic equipment. If you have questions about the interaction between your phone and any other piece of electronic equipment, ask the equipment manufacturer.

Drive safely

When you are driving, T-Mobile encourages you to use your phone in a safe and sensible manner. Here are a few tips:

- Assess road conditions before answering your phone. Your safety is more important than any call.
- Prepare your hands-free headset, if you have one, or turn on your speakerphone, before you start moving.
- Keep your phone close. If it rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.
- Remember that laws prohibiting or restricting the use of a cell phone while driving may apply in your area.

Emergency dialing

Although all phones are equipped with 9-1-1 emergency calling, this phone may or may not permit its location to be approximated during a 9-1-1 call.*

* Availability of this feature depends on upgrades to the (a) wireless network and (b) 9-1-1 calling system that are required to be installed by the local 9-1-1 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength, and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped, or refused. The phone's approximate location is transmitted to the local 9-1-1 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

Information about safeguarding handsets

T-Mobile encourages customers to take appropriate measures to secure their handsets and invites them to take advantages of the features available on this handset to help secure it from theft and/or other unauthorized access and use. This handset has a locking function (e.g., user-defined codes or patterns) that can serve as a first line of defense against unauthorized use or access to stored information. Preloaded security applications that allow customers to track or locate misplaced devices can be found on several T-Mobile devices. Remote locking and wiping capabilities are also available to T-Mobile customers that have elected to subscribe to the Mobile Security service offered by our partner, Asurion, along with insurance to help replace lost or stolen devices. Lost or stolen devices should be immediately reported to T-Mobile so that proper measures can be taken to protect accounts. For additional information visit: www.t-mobile.com/devicesecurity and <http://www.t-mobile.com/Company/PrivacyResources.aspx>.

Note: Mobile Security is a service provided by Asurion Mobile Applications and is not an insurance product.

Approved Firmware Versions: This device will only operate with firmware versions that have been approved for use by T-Mobile and the device manufacturer. If unauthorized firmware is placed on the device it will not function.

Get to know your phone



Set up your phone


Insert the microSIM card

- 1 Insert the microSIM eject tool (or a small bent paperclip) into the small hole next to the microSIM card tray.
- 2 Pull out the microSIM card tray, and place the microSIM card (contacts faced down) into the tray.
- 3 Insert the microSIM card tray into its slot.



Charge the phone

- 1 Connect the phone to the power adapter using the provided USB cable.
- 2 Plug the power adapter into an electrical outlet to start charging.



Turn on the phone

- 1 To turn on the phone, press and hold the POWER button.
- 2 When the phone goes to sleep mode, briefly press the POWER button and then pull up the ring to unlock.

